

**ASAHI PENTAX**



**SV**  
**Super S2**

この補足説明書はアサヒペンタックス S1 / S3 の英文使用説明書  
と一緒にお客様へお渡しく下さい。

The new Asahi Pentax SV and Super S2 cameras are so new that they are not yet being exported and the instruction booklet for these new models has not been completed. This instruction sheet is supplied with the instruction manual for the Asahi Pentax S1/S3 cameras to serve you to fully understand the different features of these new models.

The models SV and Super S2 are identically same as the Asahi Pentax model S3, with the exception of the following features :


**MODEL SV** has a new built-in self-timer and an automatic zero-resetting film counter.

**MODEL SUPER S2** has an all-new fully automatic Super-Takumar 55mm f2 lens, and is equipped with the same micro-prism Fresnel screen as in the Asahi Pentax S1 and S2.

The following pages explain the above different features and how to operate them properly.

# ASAHI PENTAX SV


Turn the self-timer cocking wheel (B) clockwise as indicated by the arrow mark until it stops. When you depress the self-timer release button (A), the shutter will be released in about 10 seconds. If you depress the release button (A) after turning the wheel (B) about 50 degrees, the shutter will be released in about 5 seconds. Thus, you can adjust the shutter release time between 5 and 10 seconds as you wish. The cocking wheel (B) can be turned before or after you cock the rapid wind lever of the camera. Remember that the shutter is released when the V-mark (D) comes to the front, as illustrated by



the left-side photograph.

The new automatic zero-resetting film counter does not require any instruction . . . it works automatically. No matter where the film counter is positioned, it automatically re-sets to -2 when you open the back of the camera. Load your new film, make two blank exposures, and the counter shows "0" automatically, indicating that you are now ready to take the first picture.

For operation of the other features, please refer to the instructions given for the Asahi Pentax S3.



# ASAHI PENTAX Super S2

The Asahi Pentax Super S2 has a fully automatic Super-Takumar 55mm f2 lens, which you can operate exactly same as the Auto-Takumar 55mm fl. 8 lens for the model S-3. The diagonal microprism Fresnel screen is same as the viewing screen built in the models S1 and S2.



The all other features can be operated exactly in accordance with the instructions given for the Asahi Pentax S3.

Should your Asahi Pentax cameras require warranty service, described on the last page of our instruction booklet, they should be sent to us, or to the dealer from whom you originally bought them, or to our authorized repair centers or representatives in the country where such dealer is located. When you desire to have warranty service performed outside of the country where you originally purchased your equipment, our authorized repair centers or representatives in the country outside of where you originally bought it will charge you a minimum servicing fee. The Asahi Pentax equipment is sold to you for your own use and not for the purpose of resale, unless you have purchased it for your friends. In accordance with our international distributionship agreements, you are not authorized to re-sell our products. Our warranty shall not accompany resold cameras, and we will not assume any responsibility against import duty or any other tax levied on the Asahi Pentax equipment imported for the purpose of resale without our written consent.