


SELF-TIMER


Direct coupled automatic pull-in type.


Accurate and simple operation.

DIRECTIONS



FIG, A



1. Point (A) to be inserted into the Shutter Release Hole or Shutter Button.
2. For Leica and similar cameras turn the point (B) to the right or left to adjust the length of point (C) and then turn the point (D) downward until it stops while holding the point (B) firmly.
3. Wind the cogged wheel (E) to the right until it stops. Now it is ready to photograph the subjects focussed by putting down the point (F). This Timer when fully wound will run for 18 seconds. Running time can be adjusted as desired by the indicate number shown in the window on the body to Timer.
4. To use for Leica and similar put  (supplied with all Self-Timers for free of charge) on the point (A) as shown in Fig. A.

(PRINTED IN JAPAN)